

=====
Version 0.932018-05-17
=====

- * Cleaner initialization.

=====
Version 0.922018-05-16
=====

- * Improved Art-Net and sACN network traffic filtering.
- * Optimized RDM table of device memory organization.
- * Changes to memory management.
- * Fix: Display content used to appear shifted occasionally.
- * DMX outputs are now turned off if low supply voltage is detected.
- * Improved displaying of fatal errors.

=====
Version 0.912017-11-20
=====

- * All RDM UUIDs and MAC addresses are now listed in the device info screen.
- * Improved display of network address information.
- * Changed memory management:
 All dynamically allocated memory is now managed by a single heap.

=====
Version 0.902017-11-07
=====

- * First release.