===
Version 0.97   2019-06-07
===
* Support for Art-Net 4:
        * Enabled by default.
        * Replaces previous "independent universes" feature.
        * In Art-Net 4 mode, the node does not expose a second virtual network
          interface.
* Improved factory presets:
        * Selection of start universe when loading a factory preset.
        * User may choose whether he wants to adjust the network settings when
          loading a factory preset.
        * Loading a factory preset has fewer side effects.
* DMX buffers are flushed when protocol changes.
* Relaxed DMX refresh rate by default.

===
Version 0.96   2019-05-14
===
* Introducing simple user input locking in additon to password locking.
* Fixed regression with non-zero start code sACN data packets.

===
Version 0.95   2019-05-02
===
* Merging can now be turned off.
* The refresh rate can now be changed between max. (ca. 44 Hz) and relaxed
  (ca. 30 Hz).
* Fixed a merging bug that could leave the device in a state where it was
  impossible to send channel values to the outputs below a certain minimal
  level.
* Reworked DMX generation engine.
* Firmware version is now reported correctly via Art-Net.
* Changed RDM buffers to correct size. The buffer size was low before, which
  could lead to crashes of the device.

===
Version 0.93   2018-05-17
===
* Cleaner initialization.

===
Version 0.92   2018-05-16
===
* Improved Art-Net and sACN network traffic filtering.
* Optimized RDM table of device memory organization.
* Changes to memory management.
* Fix: Display content used to appear shifted occasionally.
* DMX outputs are now turned off if low supply voltage is detected.
* Improved displaying of fatal errors.

===
Version 0.91   2017-11-20
===
* All RDM UIDs and MAC addresses are now listed in the device info screen.
* Improved display of network address information.
* Changed memory management:
   All dynamically allocated memory is now managed by a single heap.

===
Version 0.90   2017-11-07
===

* First release.